

NESS 7 x 7 RAKED TREE KIT

Fitment: 2014 and later HD FLT and FLH Models

Part Number: 20-389



ARLEN
NESS

Thank you for purchasing this Arlen Ness, Ent. product. We believe our products are the best available and engineered to provide a lifetime of use. Some specific Hand tools, Service Manual for your year and Motorcycle model, are all you need to complete this installation. Please retain these installation instructions for future reference. To ensure proper installation, a qualified motorcycle technician should perform the installation.

Bill of Materials:

- 1 – Top Triple Tree
- 1 - Bottom Triple Tree
- 2- 49mm Travel Limiters
- 1-Tube Blue Thread Locker
- 7- 3/8 AN Washers
- 7 – 3/8 -16 x 1 -1/2 “ Socket Head Bolts
- 1 - 20-389 Sheet of Instructions
- 1 - Limit – 1 Travel Limiter Instructions
- 1 – Nacelle I_20-389 – I Template

Attention: Do not lower Forks, Standard Fork Legs only! Do not use with Tour pack. On all applications, we recommend, using a Goodridge Brake Line Kit. The part number will vary based on Handlebar Height, Pullback, and model.

Steps:

1. Remove Fairing, Fork, and Tree Assembly, as instructed in the Service Manual.



(Picture #1)

2. Refer to instruction sheet, **Limit-I** to install Neoprene Travel Limiter for your specific Wheel and Fender combination. **Note: Do not Lower Forks, Standard Fork Length only.**
3. **2015 – Up Road Glide models only:** When re-installing the Gauge Nacelle, you will need to trim the shaded area of the templates on the following page. Pictures shown below of template placement. Use the same template for both sides of the Nacelle.



(Picture #2)

4. Install Forks and Fairing, as instructed in the Service Manual. **Note: The seven OEM Triple Tree Pinch Bolts are 5/16" diameter. The 20-389 features 3/8 – 16 Pinch Bolts. Install one 3/8 AN Washer on each bolt, add a drop of blue thread locker and install the Seven Pinch Bolts and torque to 25 ft. lbs.**